

Installation of Ifö Cera wash basin 2362 and Ifö pedestal 4315

Note that this pedestal is not traditional in that it provides no support for the sink. It is merely a cover for the pipe. While bolts and nuts are provided, you will need to purchase new ones as those provided will not fit in the US because threading standards are different in Europe.

1. Once you know where you want the wash basin located, you need to locate where the bolts that hold up the wash basin will go. To do this, hold the wash basin in place and place the pedestal centered beneath the basin with the two just barely touching. Keep in mind that while the basin is flush with the wall, the pedestal should be placed 1-3/16" to 2" from the wall (this range of 1-3/16" to 2" allows for wall imperfections only). It should be clear that there is only one location and fit for the pedestal (see spec. sheet for Cera 2362).
2. Once you have this set up, mark the location for the bolts (two) for the wash basin.
3. Remove the pedestal and install the wash basin.
 - 3.1. First, install the 1/2" diameter bolts (not provided) into the wall.
 - 3.2. Next, slide the bolts through the holes in the wash basin.
 - 3.3. Install the white plastic bolt holders (provided) with the bolt coming all the way through.
 - 3.4. Now install the metal washer, followed by the plastic washer (both provided) and the nut (not provided). Leave the bolts somewhat loose so the basin can be slightly lifted to allow for installation of the pedestal.
4. Slide in the pedestal so it sits just beneath the groove under the wash basin (see spec. sheet for Cera 2362). You should notice there is only one location for the pedestal (the range 1-3/16" to 2" wall distance allows for wall imperfections only).
5. Tighten the bolts using the plastic bolt holders to adjust the sink to level and help lock in the pedestal. The plastic bolt holders are off-center so they can be turned to create the best fit.
6. The pedestal does not provide support for the wash basin; rather it is a decorative cover for the pipe. The bolts are what are holding up the wash basin. The pedestal will be held in securely in place by the tight fit in the groove of the wash basin.
7. Install the white bolt covers (provided), by snapping them into the white plastic washers already installed.

